

SLUSH PUPPIE® MACHINE INSTRUCTIONS FOR USE

Model Number BH9268. Product Ref: 9047. Power Specification: 220-240V, 50/60Hz, 25W, V6.

CONTENTS

Safety Information	2
Before You Begin	3
Using the Machine	4-5
Storage and Maintenance	5

SAFETY INFORMATION

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING AND USING YOUR SLUSH PUPPIE MACHINE. WE RECOMMEND YOU KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.

- Never use any attachments or tools not included with the SLUSH PUPPiE Machine. The use of these attachments may cause, fire, electric shock or injury.
- Never use the appliance for anything other than its intended use. The appliance is for household use only. Do not use outdoors.
- This appliance is intended to be used in the household and similar applications such as; farm houses, by clients in hotels, motels and other residential type environments. It is not suitable for use in staff kitchen areas in shops, offices and other working environments.
- Never allow children to use the SLUSH PUPPIE Machine, close supervision is necessary when this appliance is in use near children.
- X Never let the power cord hang over the edge of the worktop, touch hot surfaces, become knotted, trapped or pinched.
- X Never place on or near a heat source.
- Never leave the SLUSH PUPPiE Machine unattended during use.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory, or mental capabilities. This machine can also be used by persons with lack of experience and knowledge if they have been given

- Never touch the exposed metal parts of the appliance during use as they will become very hot.
- Never operate the SLUSH PUPPiE Machine by means of an external timer or separate remote control system.
- Never immerse the power cord or plug into water or any other liquid. This is to protect against electric shock.
- Always ensure the SLUSH PUPPiE Machine is only used by a responsible adult.
- Always use the SLUSH PUPPiE Machine on a stable level surface.
- Always ensure that hands are dry before handling the plug or switching on the SLUSH PUPPiE Machine.
- Always unplug this unit when not in use and before cleaning
- Always allow the SLUSH PUPPIE Machine to fully cool down before cleaning or storing.
- Always carry out regular checks on the SLUSH PUPPiE Machine and power cord.

supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Electrical Safety

PLEASE READ THESE INSTRUCTIONS THOROUGHLY BEFORE USING THE SLUSH PUPPIE MACHINE OR CONNECTING IT TO THE MAINS ELECTRICITY SUPPLY.

- A 3 amp BS1362 ASTA approved fuse must be fitted.
- There are no user serviceable parts inside the SLUSH PUPPIE Machine. In order to avoid hazard always refer servicing to a qualified service personnel.
- Do not allow the SLUSH PUPPIE Machine to be exposed to rain or moisture during use or storage.
- Before switching on, make sure that the voltage of your electricity supply is the same as that indicated on the SLUSH PUPPiE Machine's rating plate. Connecting it to any other power source may cause damage.
- The supply cord cannot be replaced. If the cord is damaged, the appliance should be disposed of for recycling.

BEFORE YOU BEGIN

Identifying Parts:

- 1. Lid
- 2. Ice shaving chamber
- 3. Main body
- 4. Central Column

- 5. Selector dial.
- 6. Mixing paddle
- 7. Jug



What you will need...

We recommend that you use SLUSH PUPPiE branded syrups. Carefully follow the instructions on the syrup bottle. **To make 1 litre of Slush Puppie, mix 835ml**

of shaved ice to 165ml syrup. This is a guide. Should your mixture not produce the desired slush, you can add more ice or syrup as necessary.

Ice Cubes

Make sure you have enough ice cubes on hand to fill the Ice Canister.

Syrup

We recommend SLUSH PUPPiE branded syrup. You can also use fruit juice!

Cups

Use your own, or purchase the Slush Puppie Cups (9oz).

Jug Measuring

PLEASE NOTE: There are two measurements on the jug. Use SLUSH PUPPIE measurements for SLUSH PUPPIE syrups and use the embossed measurements for all other liquids.

Making a SLUSH PUPPiE Slushie

Using the SLUSH PUPPiE measurements on the jug, pour the syrup into the jug to the required level. The rest of the jug will be filled with ice from the machine to create the perfect SLUSH PUPPiE Slushie!





TIP: Using Your SLUSH PUPPiE Machine

Your SLUSH PUPPiE Machine can make a maximum of 1 litre of SLUSH PUPPiE mix in one go. **DO NOT** exceed the maximum capacity of 1 litre of liquid in the SLUSH PUPPiE jug.

USING THE MACHINE

Making Slush Puppies



 Place the ice shaving chamber into the top of the main body. This may require some adjustment as this will only fit in if the position is correct.



Once firmly in place, lock the canister using the knob on top. This will click into place when fully locked.



3. Now place the mixing paddle into the jug as shown above.



4. Choose your desired liquid. This could be SLUSH PUPPiE syrups, fizzy drinks or fresh juices. Using the clear markings, fill the jug to the desired amount. For SLUSH PUPPiE syrups, use the printed markings. For other liquids, use the embossed markings.



Place the jug into the machine as shown in the image and rotate clockwise.



6. It is important the jug looks like the above image and is pushed as far clockwise as it will go.



 Now add your ice to the canister. It is important you do not fill over the max fill line clearly shown on the canister.



8. Using the dial on the front, you can alter the settings depending on your requirements. Coarse will give you thicker chunks of ice and fine will give thin shavings to create a slushie.



Now place the lid on. There are two latches on the lid.
The end with the On/Off markings should be facing towards the back

The end with the On/Off markings should be facing towards the back of the machine. Now rotate the lid anti-clockwise and the machine will begin shaving your ice. To turn off the machine, rotate the lid clockwise.

USING THE MACHINE



You will notice that the ice will only fill the jug half full. Please refer back to Step 6 to fill a further half if required. If you require 500ml of slush, crush one round of ice. For 1 litre of slush, crush two rounds of ice.



11. Once mixed, turn the machine off by turning the lid clockwise. Remove the mixing jug by turning it anticlockwise.



12. Once removed remove the mixing paddle from the jug and hand stir the slushie mixture with a spoon to ensure consistency.



13. Serve your slushie in the cups provided or a glass and enjoy!

STORAGE AND MAINTENANCE

Cleaning and Care To clean your SLUSH PUPPiE Maker:

- 1 Unplug the SLUSH PUPPiE Machine from the mains electricity supply and allow it to cool completely.
- 2 Remove all detachable parts.
- 3 Clean the detachable, non-electronic parts in lukewarm water with some washing-up liquid and rinse them under a tap.
- 4 Clean the outer surface of the SLUSH PUPPiE Machine with a soft damp cloth.



IMPORTANT

Before cleaning your SLUSH PUPPiE Machine, make sure the machine is turned off.



IMPORTANT

DO NOT immerse the Motor Unit in water or any other liquids.



DO NOT use coarse or abrasive cleaners or steel wool to clean the SLUSH PUPPiE Machine.



IMPORTANT

WARNING! Contains functional sharp edges. Please take care when cleaning.



Never spray or apply cleaning products directly onto the SLUSH PUPPiE Machine. If necessary, apply cleaner to a soft cloth instead.

IMPORTANT

DO NOT use a dishwasher to clean your SLUSH PUPPiE Machine.

Storage

To safely store your SLUSH PUPPiE Machine:

- 1 Make sure the SLUSH PUPPiE Machine is turned off.
- Unplug the SLUSH PUPPiE Machine from the mains electricity vlagus
- 3 Make sure the SLUSH PUPPiE Machine has completely cooled and is clean before storing.
- 4 Store the SLUSH PUPPiE Machine in its original packaging in a clean dry place. DO NOT allow the SLUSH PUPPiE Machine to be exposed to rain or moisture during use or storage.

Servicing

If you drop or damage your SLUSH PUPPiE Machine do not use it until it has been examined by an authorised service centre or appliance technician. Servicing must only be carried out by qualified service personnel. The SLUSH PUPPiE Machine is for household use only.

Technical Specification

Voltage: 220-240 V 50/60 Hz Power: 25 Watts

Capacity: 1 litre

Power Specification: 220-240V, 50/60Hz, 25W.

WARNING! This is not a toy. Wash before first use. Not suitable for dishwasher use. Remove all packaging before use. Unplug before cleaning. Do not immerse electrical parts in water or any other liquid. Keep out of the reach of children. Indoor use only. Read instructions carefully before use and retain this information for future reference. WEEE products should be disposed of by handing it over at a designated collection point. For more information about where you can drop off your waste product for recycling please contact your local authority. For customer services contact Sales@Fizzcreations.com

© 2022 SLUSH PUPPiE®. SLUSH PUPPiE® is a registered trademark of The ICEE Company, a Subsidiary of J&J Snack Foods Corp.









